




ELECTRIC GRILL

Pos	Code	Description
0001	CR0979280	MICROSWITCH [C] GRID CWE
0002	CR0979290	SPRING [C] GRID CWE
0003	CR0979300	KNOB [C]
0004	CR0935863	HEATING ELEMENT [C] 400V M40
0005	CR0979320	HEATING ELEMENT [C] 400V NR03
0006	CR1221460	TRAVERS.REGGI RESISTENZE CWE 60-70 M40
0007	CR0975930	SCRAPER [C]
0008	MACM187301	CONTACTOR [C]
0009	CR1071980	ASS. PIANO NGWE 70 M40
0010	MA710300	SWITCH [C]
0011	CR1071790	CRUSCOTTO NGW94E - NGW74E
0012	CR0587500	ORANGE PILOT LAMP [C]
0013	CR1095040	KNOB [C] SHAFT E15 D. 6
0014	CR0935250	BUSH [C]
0015	CR1095230	LABEL [C] ENERGY REGULATOR
0016	CR0588510	GASKET [C] CONTROL PANEL 900
0017	CR0588950	EXTENSION [C] DRAIN PASTA COOKER 900
0018	CR0587650	GASKET [C] SHAFT
0019	MA1988500	HANGER [C]
0020	MA1037112400	FAIRLEAD [C]
0021	MA1037114500	LOCK NUT [C]
0022	MA1878400	TERMINAL BLOCK [C]
0023	CR0588170	6 POLES TERMINAL BLOCK [C] 450V
0024	LA65080250	ENERGY REGULATOR [C]
0025	CR1220540	ASS.BACINELLA C/TRAVERSINO CWE60/70 M40
0026	CR0937620	CABLAGGIO CUOCIWURSTEL 60 M40/60