




Apach


CHEF *line*


LHST50




















(*) Recommended spare part.

Page	Spare part position	Spare part code no.	Old code number	Description	U.m.
1	1	74141		STANDARD HOOD FOR HOOD-TYPE DISHWASHER	NR
1	2	927088	CWM7	MAGNET FOR HOOD MICROSWITCH	NR
1	3	70212		SPACER	NR
1	4	80998		SCREW	NR
1	5	74068		HOOD DRIVE	NR
1	6	80638		TOP BACK PANEL	NR
1	7	74162		BACK PANEL	NR
1	8	80275	C.80275	COIL HOOKING BRACKET - COMPLETE	NR
1	9	80277	C.80277	SPRING HOOKING SLIDE	NR
1	10	926007	CMT549	EXTENSION STEEL SPRING FOR DISHWASHER	NR
1	11	80190	C.80190	BRACKET	NR
1	12	926009	DAG332	SPRING ADJUSTMENT HOOK	NR
1	13	74923		HOLDER TENSION SPRING	NR
1	14	80105	C.80105	PARE-CHOCS CAPOT	NR
1	15	74521		HANDLE NH/GH50	NR
1	16	41042	C.41042	ADHESIVE PLUG	NR
1	17	80240		RACK FRAME	NR
1	18	69571		LEFT SIDE PANEL	NR
1	19	69572		RIGHT SIDE PANEL	NR
1	20	80078	C.80078	support bracket	NR
1	21	73100		FOOT	NR
1	22	74550		FRONT PANEL	NR
1	23	70808		LEFT LEVER	NR
1	24	70809		NOT IN PRICE-LIST	
2	1	74043		WIRING PANEL	NR
2	3	215042-5		MAIN BOARD GET50.2 F MD	NR
2	4	229042		AUXILIARY CONTACT	NR
2	7	73350		CONTACTOR	NR
2	10	220011	REB220011	TERMINAL BLOCK	NR
2	11	228010		FUSE	NR
2	18	80934		FLAT CABLE	NR
2	19	74902		CONTROL KEYBOARD	NR

(*) Recommended spare part.

Page	Spare part position	Spare part code no.	Old code number	Description	U.m.
2	20	419036		INTERFACE BOARD DISTANCE KEEPERS	NR
2	21	417119		NUT	NR
2	22	74708		NOT IN PRICE-LIST	
2	23	CWP2		FOOT	NR
2	24	DEP521		CABLE GLAND	NR
2	25	80997		power cable	NR
2	26	80731		PVC CURTAIN FOR ELECTRIC PROTECTION	NR
2	28	H.228047		FUSE-HOLDER	NR
2	29	H.228048		PLUG	NR
2	30	228010		FUSE	NR
2	35	80804		DOUBLE SWITCH	NR
2	37	226126		push button case	NR
2	38	227064		BUTTON	NR
2	45	226095	REB226095	DOUBLE CONTACT PUSH-BUTTON	NR
3	1	121146		STAINER	NR
3	2	74069		HEATING ELEMENT	NR
3	3	437086	REB437086	PACKING OF THE TANK RESISTANCE	NR
3	4	80871		MAGNETIC DOOR SWITCH	NR
3	5	236052		THERMOSTAT 90°+/-3°C	NR
3	6	926189	DRT140	CONTACT SAFETY-THERMOSTAT	NR
3	8	74052		BRACKET	NR
3	9	999348		DETERGENT TANK FITTING	NR
3	10	143194	REB143194	PIPE	MT
3	11	143258		"SANTOPRENE" PIPE	NR
3	12	209043		DETERGENT DOSING PUMP	NR
3	13	121993		filter aid dispenser	NR
3	17	231016		TEMPERATURE PROBE	NR
3	18	H.775489-001		Support temperature probe	NR
3	19	107013		AIR TRAP for pressure switch	NR
3	20	456073		O-RING	NR
3	21	142058		OVERFLOW PIPE	NR
3	22	456081		O-ring	NR

(*) Recommended spare part.

Page	Spare part position	Spare part code no.	Old code number	Description	U.m.
3	23	121120		STAINER	NR
3	24	429072		RING NUT	NR
3	25	456076		O-RING	NR
3	26	74073		ASPIRATION AND DRAIN BODY	NR
3	27	127082		DELIVERY WASH HOSE	NR
3	28	CFS1		HOSE CLAMP	NR
3	29	143252		DRAIN HOSE	NR
3	30	143235		PIPE	MT
3	31	224031		PRESSURE SWITCH	NR
4	1	69017		MAINFOLD	NR
4	2	80178	C.80178	GASKET	NR
4	3	80174		PIPE FITTING	NR
4	4	CFS1A		HOSE CLAMP	NR
4	5	69020		PIPE	NR
4	6	CFS1		HOSE CLAMP	NR
4	7	69016		MAINFOLD	NR
4	8	127085		DELIVERY WASH HOSE	NR
4	9	423008	CFS24	HOSE CLAMP	NR
4	10	127082		DELIVERY WASH HOSE	NR
4	11	74073		ASPIRATION AND DRAIN BODY	NR
4	15	441009	REB441009	GASKET	NR
4	17	429073		RING NUT	NR
4	18	437102		GASKET	NR
4	21	CGR3037		O-ring	NR
5	1	69020		PIPE	NR
5	2	80174		PIPE FITTING	NR
5	3	927322	CFS14	HOSE CLAMP	NR
5	4	143010	SPG61	RUBBER PIPE 12X19,5	MT
5	5	143268		JUNCTION "Y"	NR
5	6	143270		INLET WRAS PIPE	NR
5	7	69016		MAINFOLD	NR
5	8	104060		BOILER	NR

(*) Recommended spare part.

Page	Spare part position	Spare part code no.	Old code number	Description	U.m.
5	9	926189	DRT140	CONTACT SAFETY-THERMOSTAT	NR
5	10	456002	REB456002	O-ring	NR
5	11	231016		TEMPERATURE PROBE	NR
5	12	74086		HEATING ELEMENT	NR
5	13	69870		BOILER HEATING ELEMENT PROTECTION	NR
5	14	423010	CFS8	HOSE CLAMP	NR
5	15	143005	SPG10	LINER RUBBER PIPE 5X12 - BLACK	MT
5	16	H.775601		PIPE	MT
5	17	209042		DOSING PUMP	NR
5	18	121993		filter aid dispenser	NR
5	19	144010	REB144010	NON RETURN VALVE	NR
5	20	240016	DEV3S16	SOLENOID VALVE	NR
5	21	437041	REB437041	GASKET	NR
5	30	74052		BRACKET	NR
5	31	143261		HOSE	NR
5	36	69871		PROBE HOLDER	NR
6	1	80184		SEALING RING	NR
6	3	70286		TOP PIVOT	NR
6	4	990132		RINSE AND WASH ARM	NR
6	5	990137		RINSE AND WASH ARM	NR
6	8	308039		PLASTIC ARM BUSH	NR
6	9	454007		PIN	NR
6	10	325113		PIVOT	NR
7	1	74122		ELECTROPUMP	NR
7	3	335015		WASHPUMP FUN	NR
7	4	206002	REB206002	CAPACITOR	NR
7	5	69400		support bracket	NR
7	6	141008		WASHPUMP SHAFT SEAL	NR
7	7	141009		WASHPUMP SHAFT SEAL	NR
7	8	124057		ELECTROPUMP IMPELLER	NR
7	10	456078		O-RING	NR
7	11	480148		PLUG	NR

(*) Recommended spare part.

Page	Spare part position	Spare part code no.	Old code number	Description	U.m.
7	12	429074		RING NUT	NR
7	13	486242		SCREW	NR
7	14	116041		ELECTROPUMP HOUSING	NR
7	15	74122HZ		ELECTROPUMP 60HZ	NR
7	16	124060		ELECTROPUMP IMPELLER	NR
8	1	468165	REB468165	UPPER RINSE PIPE CONNECTOR	NR
8	2	75402		RINSE PIPE GASKET	NR
8	3	429075		RING NUT	NR
8	4	H.775611-001		PIPE	MT
8	5	468205		PIPE CONNECTION	NR
8	6	476008		SPHERE	NR
8	7	437083		GASKET	NR
8	8	499092		diaphragm valve vent	NR
8	9	144022		DRAIN PUMP VENT VALVE	NR
8	10	80702		DRAIN HOSE	NR
8	11	80712		BRACKET	NR
8	12	130177		DRAIN PUMP 50HZ	NR
8	13	70097		DRAIN HOSE	NR
8	16	143252		DRAIN HOSE	NR
8	17	144991B		DRAIN PUMP VENT VALVE	NR
8	18	80637		support bracket	NR
8	19	CFS18		HOSE CLAMP	NR
8	20	CFS1		HOSE CLAMP	NR
8	22	130181		DRAIN PUMP 60 HZ	NR